

UPDATE BOOTLOADER ON RUT9 SERIES DEVICES

1. Connect any LAN port of RUT via Ethernet cable to your PC (all other Ethernet ports must be empty).
2. Hold reset button while powering the device on. Release the button 3s after supplying the power. All Ethernet LEDs should be blinking now.
3. Use incognito mode of your web browser type this address: <http://192.168.1.1/uboot.html>
4. Select the boot loader file "uboot_for_tlt_rut900_webui.bin" and click "Update U-Boot"

U-BOOT UPDATE

You are going to update U-Boot bootloader on the device.
Please, choose file from your local hard drive and click Update U-Boot button.

uboot_rut900_2016-06-22.bin

WARNINGS

- do not power off the device during update
- if everything goes well, the device will restart
- you can upload whatever you want, so be sure that you choose proper U-Boot image for your device
- updating U-Boot is a very dangerous operation and may damage your device!

Teltonika solutions:

www.teltonika.lt

5. Bootloader update is successful and the device is restarted within 3s of displaying „Update In Progress“ window

UPDATE IN PROGRESS

Your file was successfully uploaded! Update is in progress and you should wait for automatic reset of the device.
Update time depends on image size and may take up to a few minutes. You can close this page.



Teltonika solutions:

www.teltonika.lt

6. If you get an error message „Update Failed“ means that current bootloader expects different file format. Go to the step 4 and use file "uboot_for_tlt_rut900_no_checksum.bin".

UPDATE FAILED

Something went wrong during update Probably you have chosen wrong file (too big or too small) or you were trying to update ART on device with unknown FLASH type (and size) which is not allowed. Please, try again or contact with the author of this modification. You can also get more information during update in U-Boot console.

Teltonika solutions:

www.teltonika.lt