

Open VPN manual

1.	TLS		2
	1.1. Do	ownload software	2
	1.2. In:	stalling software	2
	1.3. Cr	eating certificates	2
	1.4. Co	onfigure RUT9xx as an OpenVPN TIs server	4
	1.5. Cc	onfigure RUT9xx as an OpenVPN TIs client	7
	1.6. Cc	onfigure Computer as an OpenVPN TIs server	9
	1.7. Co	onfigure Computer as an OpenVPN TIs client	10
2.	Static l	<ey< td=""><td>11</td></ey<>	11
	2.1. Co	onfigure your computer as a Server	11
	2.2	Configure RUT9xx as a Client	11
	2.3	Configure your computer as a client	14
	2.4	Configure Rut9xx as a server	14
	2.5	Connect to server	15



1. TLS

1.1. Download software

1.1.1. Download "**OpenVPN windows installer**" 64bit or 32bit software. (https://openvpn.net/index.php/open-source/downloads.html)

1.2. Installing software

- 1.2.1. Press "Next"
- 1.2.2. Press "I Agree"
- 1.2.3. If you want to create certificates using this computer check "OpenSSL Utilities" and "OpenVPN RSA Certificates Management Scripts" checkboxes (should be checked all boxes) otherwise leave default settings.

OpenVPN 2.3.10-I601 Setup		x						
Choose Components Choose which features of OpenVPN 2.3. 10-I601 you want install.								
Select the components to install, service if it is running. All DLLs a	/upgrade. Stop any OpenVPN processes or the OpenVPN are installed locally.	I						
Select components to install:	OpenVPN GUI OpenVPN File Associations OpenSSL Utilities OpenVPN RSA Certificate Management Scripts Add OpenVPN to PATH Add Shortcuts to Start Menu	* III						
Space required: 3.9MB	Add OpenVPN shortcuts to the current user's Start Menu.							
Nullsoft Install System v2,46-101 –	< <u>B</u> ack Next > Can	cel						

- 1.2.4. Press "Install" and wait for installation to complete.
- 1.2.5. Press "Next"
- 1.2.6. Press "Finish"

1.3. Creating certificates

- 1.3.1. Open cmd.exe (Start->Run->cmd.exe)
- 1.3.2. If you installed OpenVPN in default folder write

2

"cd \Program Files\OpenVPN\easy-rsa" otherwise use your created file tree.



- 1.3.3. If you doing it for the first time write command "init-config" it will reset all certificate system. (if you have already created certificates on this computer and if you don't want to recreate all your certificates skip this step .)
- 1.3.4. This step is optional (It will help to create certificates easier because you are creating hint for the certificate data). A new file will appear C:\OpenVPN\easy-rsa\vars.bat. Open it with your favorite text editor like notepad and edit these lines: After that save and close vars.bat file.

set KEY_COUNTRY= your_text_1
set KEY_PROVINCE= your_text_2
set KEY_CITY= your_text_3
set KEY_ORG= your_text_4
set KEY_EMAIL= your_text_5

1.3.5. To build root keys write these commands in cmd.exe: "vars", "clean-all", "build-ca". Now you will be asked to write information (one line at the time) about your certificate:

Country Name <2 letter code> [US]:us
State or Province Name (full name) [CA]:ca
Locality Name (eg, city) [SanFrancisco]:san
Organization Name (eg, company) [OpenUPN]:name
Organizational Unit Name (eg, section) [changeme]:name
Common Name (eg, your name or your server's hostname) [changeme]:Unique_name
Name [changeme]:name
Email Address [mailChost.domain]:emailCcompany.com

Only "**Common Name (eg, your name or your server's hostname) [changeme]:**" is important because it must be unique name.

Now you have new file in your C:\OpenVPN\easy-rsa\keys catalog - "ca.crt"

This step should be done once and created file must be used in server and all clients' settings.

1.3.6. To create server certificate write these commands in cmd.exe: "vars", "build-key-

server server". Now you will be asked to write information (one line at the time) about your certificate:

Country Name (2 letter code) [US]:us
State or Province Name (full name) [CA]:ca
Locality Name (eg, city) [SanFrancisco]:san
Organization Name (eg, company) [OpenVPN]:open
Organizational Unit Name (eg, section) [changeme]:name
Common Name (eg, your name or your server's hostname) [changeme]:Unique_name_2
Name [changeme]:name
Email Address [mailChost.domain]:mail
Please enter the following 'extra' attributes
to be sent with your certificate request
A challenge password []:password
An optional company name []:name
Only "Common Name (ex. your name or your server's hostname) [changeme];" (it

Only "**Common Name (ex. your name or your server's hostname) [changeme]:**" (it must be unique) and "**A challenge password []**" (you'll have to use it in all clients certificates) are important.

After that you will be asked to agree, press "y" and "enter" two times.

3



Now you have new files in your C:\OpenVPN\easy-rsa\keys catalog – "server.crt" and "server.key".

- 1.3.7. To create Diffie Hellman file write to cmd.exe: "build-dh". Now you have new file in your C:\OpenVPN\easy-rsa\keys catalog "dh1024.pem" (This is the last file required for server configuration).
- 1.3.8. To create Client certificate files write to cmd.exe: "vars", "build-key <desired unique remote user name>" (the same user name will be used in certificate data). Now you will be asked to write information (one line at the time) about your certificate:



Only "Common Name (eg, your name or your server's hostname) [changeme]:" (it must be unique and the same as in command you entered in cmd.exe <desired unique remote user name>) and "A challenge password []" (you'll have to use it in all clients certificates) are important. After that you will be asked to agree, press "y" and "enter" two times. Now you have new files in your C:\OpenVPN\easy-rsa\keys catalog – "unique.crt and "unique.key". (We have named these clients certificates client1.crt and client1.key)

1.4. Configure RUT9xx as an OpenVPN Tls server

- 1.4.1. Open RUT9xx web GUI and select Services -> VPN -> OpenVPN.
- 1.4.2. Create new configuration file by selecting role "**Server**" and typing configuration name which you like. Then press Add New button.

Teltonik	A Status -	Network - S	ervices 🗸 System 🗸		Logout 🖻
OpenVPN IPse	GRE Tunnel	PPTP L2TF			
OpenVPN					
OpenVPN Configu	ration				
Tunnel name		TUN/TAP	Protocol	Port	Enable
There are no openVPN	l configurations yet				
Role: Server 💌 N	ew configuration name:	Server	Add New		
					Save



1.4.3. After that you will see a line with your tunnel. Press edit button to configure server.

Server_Server	Tun_s_Server	UDP	1194		Edit	Delete	
---------------	--------------	-----	------	--	------	--------	--

1.4.4. On the opened page you will see Main Settings. After configuring press save at the bottom of the page.

OpenVPN IPsec GRE Tunnel F	PPTP L2TP								
OpenVPN Instance: Server_Server									
Main Settings									
Enable 🗹 Check this box if you want to enable OpenVPN service									
TUN/TAP	TUN (tunnel)								
Protocol	UDP •								
Port	1194 Default OpenVPN port								
LZO	Check this box if you want to enable data								
Encryption	BF-CBC 128 (default) compresion (to save data bandwidth)								
Authentication	TLS								
TLS cipher	All								
Client to client	Check if you want that clients could be able								
Keep alive	10 120 to connect to each other Leave default								
Virtual network IP address	176.16.1.0 Your virtual network IP								
Virtual network netmask	255.255.255.0 address.								
Allow duplicate certificates									
Certificate authority	Uploaded File (1.33 KB) 🔀 ca.crt								
Server certificate	Uploaded File (3.99 KB) 🔀 server.crt								
Server key	Uploaded File (912.00 B) 🗙 server.key								
Diffle Hellman parameters	Uploaded File (245.00 B) 🗙 dh1024.pem								



1.4.5. By default everyone who connects to the server will be able to connect to each other by virtual IP address, but if you want to connect to their local IP address you must add client by writing its' name (recommend to write its' unique name, for example PCclient) and pressing "add".

TLS Clients							
Here you can add your VPI	ere you can add your VPN clients so that they may be reachable from the server.						
There are no values created yet							
PCclient	Add						

1.4.6. Configure client settings as in picture below and press "save" at the bottom of the page after configuring client settings.

TLS Clients		
Here you can add your VPN clients so that they ma	y be reachable from the se	rver.
PCclient		
VPN instance name	server_Server	Leave default
Endpoint name	Name	Write name of your computer (not
Common name (CN)	PCclient	Client's unique name as in certificate (important)
Virtual local endpoint	176.16.1.6	You should write IP address which client
Virtual remote endpoint	176.16.1.5	from table bellow this picture
Private network	192.168.50.0	Write this client's subnet address with zero in the end
Private netmask	255.255.255.0	Use this Netmask

You have to choose virtual local/endpoint from these paired IP endings.

[1, 2]	[5, 6]	[9, 10]	[13, 14]	[17, 18]
[21, 22]	[25, 26]	[29, 30]	[33, 34]	[37, 38]
[41, 42]	[45, 46]	[49, 50]	[53, 54]	[57, 58]
[61, 62]	[65, 66]	[69, 70]	[73, 74]	[77, 78]
[81, 82]	[85, 86]	[89, 90]	[93, 94]	[97, 98]
[101,102]	[105,106]	[109,110]	[113,114]	[117,118]
[121,122]	[125,126]	[129,130]	[133,134]	[137,138]
[141,142]	[145,146]	[149,150]	[153,154]	[157,158]
[101,102] [121,122] [141,142] [161,162] [181,182] [201,202] [221,222] [241,242]	[105,106] [125,126] [145,146] [165,166] [185,186] [205,206] [225,226] [245,246]	[109,110] [129,130] [149,150] [169,170] [189,190] [209,210] [229,230] [249,250]	[113,114] [133,134] [153,154] [173,174] [193,194] [213,214] [233,234] [253,254]	[117,118] [137,138] [157,158] [177,178] [197,198] [217,218] [237,238]

1.5. Configure RUT9xx as an OpenVPN Tls client

- 1.5.1. Open RUT9xx web GUI and select Services -> VPN -> OpenVPN.
- 1.5.2. Create new configuration file by selecting role "client" and typing configuration name (we recommend to write same unique name as in certificate (CN)). Then press Add New button.

	IKA	Status 🗸	Network -	Services -	System -			Logout 🕒
OpenVPN I	Psec GF	RE Tunnel	PPTP	L2TP				
OpenVPN								
OpenVPN Confi	iguration							
Tunnel name			TUN/TAP		Protocol	Port	Enable	
There are no open	There are no openVPN configurations yet							
Role: Client 💌	New configu	iration name:	client1		Add New			
								Save

1.5.3. Now press "edit" button.

OpenVPN

OpenVPN Configuration									
Tunnel name	TUN/TAP	Protocol	Port	Enable					
Client_client1	Tun_c_client1	UDP	1194		Edit Delete				



1.5.4. Fill forms as in example and press save.





1.6. Configure Computer as an OpenVPN Tls server

1.6.1. In "C:\Program Files\OpenVPN\config" create file "server.opvn" which contains these settings:

server.ovpn
port 1194
proto udp
dev tun
ca ca.crt
cert server.crt
key server.key
dh dh1024.pem
server 10.8.0.0 255.255.255.0
ifconfig 10.8.0.0 255.255.255.0
route 192.168.1.0 255.255.255.0
<pre>client-config-dir " C:\\Program Files\\OpenVPN\\config \\ccd"</pre>
ifconfig-pool-persist ipp.txt
status openvpn-status.log
comp-lzo
keepalive 10 120
persist-key
persist-tun
verb 5

Firstly choose your server virtual IP address "10.x.0.0" default is 10.8.0.0, then decide whether you need or not need to use data compression. If you need it leave "comp-lzo" if don't - delete it.

- 1.6.2. In 1.6.1. settings you can see four names highlighted in green. These files should be copied in "C:\Program Files\OpenVPN\config" (the same folder as server config file).
- 1.6.3. Create folder "ccd" in directory in "C:\Program Files\OpenVPN\config\ccd". In this folder create file with unique client name for example: "unique" (the same name as used for client certificate). In this example we use name "client1". This file "client1" contains these settings:

ifconfig-push 10.8.0.9 10.8.0.10 #push routes prom IP pair table (first IP is to self, second - for client).

iroute 192.168.1.0 255.255.255.0 #example if client's network is .1.0/24

1.7. Configure Computer as an OpenVPN Tls client

In "C:\Program Files\OpenVPN\config" create file "unique.opvn" which contains these settings:

##remote.ovpn##
client
dev tun
proto udp
remote 84.150.123.101
resolv-retry infinite
nobind
route 192.168.1.0 255.255.255.0
persist-key
persist-tun
<mark>ca ca.crt</mark>
cert client1.crt
key client1.key
comp-lzo

In line starting with "**remote**" write your server IP address and port (port is usually default 1194).

"Route" – this is RUT9xx (OpenVPN server) LAN subnet.

10:00

Files with name highlighted in green should be placed in "C:\Program Files\OpenVPN\config" (the same folder as client config file).

After that open application "**OpenVPN GUI**". It should be already installed in your computer as bundle of "**OpenVPN windows installer**". Then you will see this "

" two computers with red displays. Press on it with right mouse button and select "**Connect**".



2. Static key

2.1. Configure your computer as a Server

- 2.1.1. Start "Generate a static OpenVPN key" shortcut and press enter. Then check your "C:\Program Files\OpenVPN\config" folder for new file key.txt.
- 2.1.2. Open "C:\Program Files\OpenVPN\config" and create file "static.ovpn" with content as in example:

#server
port 1194
proto udp
dev tun
secret static.key
ifconfig 172.16.0.1 172.16.0.2
comp-lzo
route 192.168.1.0 255.255.255.0
keepalive 10 120
persist-key
persist-tun
resolv-retry infinite
verb 5

2.2 Configure RUT9xx as a Client.

- 2.2.1 Open RUT9xx web GUI and select Services -> VPN -> OpenVPN
- 2.2.2 Create new configuration file by selecting role "**Client**" and typing configuration name which you like. Then press Add New button

	NIKA	Status -	Network -	Ser	vices - System -			Logout 🗗
OpenVPN	IPsec	GRE Tunnel	PPTP	L2TP				
OpenVPN	N							
OpenVPN Co	nfiguratio	on						
Tunnel name			TUN/TAP		Protocol	Port	Enable	
There are no ope	enVPN cor	figurations yet						
Role: Client	 New c 	onfiguration name:	RUT9		Add New			
								Save



2.2.3 After that you will see a line with your tunnel. Press edit button to configure server.

OpenVPN Configuration									
Tunnel name	TUN/TAP	Protocol	Port	Enable					
Client_RUT9	Tun_c_RUT9	UDP	1194		Edit	Delete			

2.2.4 Fill forms as in example and press save.

TELTO	ONIKA	Status -	Network	- Ser	rices ▼ System ▼	Logout
OpenVPN	IPsec	GRE Tunnel	PPTP	L2TP		

OpenVPN Instance: Client_RUT9

Main Settings	
Enable	V
TUN/TAP	TUN (tunnel)
Protocol	UDP -
Port	1194
LZO	
Encryption	BF-CBC 128 (default)
Authentication	Static key -
Remote host/IP address	84.15. XX.YY
Resolve retry	Infinite
Keep alive	10 120
Local tunnel endpoint IP	172.16.0.2
Remote tunnel endpoint IP	172.16.0.1
Remote network IP address	192.168.50.0
Remote network IP netmask	255.255.255.0
Max routes	100
Static pre-shared key	Uploaded File (636.00 B) 🔀



2.2.5 Network topology of this example:



2.2.6 Port forwarding rule in router RUT5xx for OpenVPN

vpn	TCP, UDP	From any host in wan	To any router IP at port 1194	Forward to IP 192.168.50.102, port 1194 in Ian	V	e Edit Delete
-----	-------------	----------------------	-------------------------------	--	----------	---------------

2.2.7 After that open application "**OpenVPN GUI**". It should be already installed in your computer as bundle of "**OpenVPN windows installer**". Then you will see this "



" two computers with red displays. Press on it with

right mouse button and select "Connect".



2.3 Configure your computer as a client

2.3.1 Start "Generate a static OpenVPN key" shortcut and press enter. Then check your "C:\Program Files\OpenVPN\config" folder for new file key.txt.

2.3.2 Open "C:\Program Files\OpenVPN\config" and create file "static.ovpn" with content as in example:

<mark>remote</mark> 84.15.xx.yy
verb 5
proto udp
dev tun
comp-lzo
ifconfig 172.16.0.2 172.16.0.1
route 192.168.1.0 255.255.255.0
<mark>secret</mark> static.key
keepalive 10 120
persist-key
persist-tun

- 2.3.2.1 In line remote write your server IP address.
- 2.3.2.2 In line ifconfig write your virtual remote and local IP address as in example in 1.4.6 item.
- 2.3.2.3 The last line is the name of your static OpenVPN key, which you generated and have (it should stay here) in "C:\Program Files\OpenVPN\config" folder.

2.4 Configure Rut9xx as a server

- 2.4.2 Open RUT9xx web GUI and select services -> OpenVPN
- 2.4.3 Create new configuration file by selecting role "**server**" and typing configuration name which you like. Then press Add New button.

TELTON	IIKA	Status -	Network	- Ser	vices 👻 System 🗸			Logout 🕒
OpenVPN	IPsec	GRE Tunnel	PPTP	L2TP				
OpenVPN								
OpenVPN Con	figuratio	n						
Tunnel name			TUN/TAP		Protocol	Port	Enable	
There are no ope	nVPN con	figurations yet						
Role: Server 🔻	New c	onfiguration name:	Test		Add New			
								Save



Tunnel name TU	IN/TAP	Protocol	Port	Enable			
Server_Test Tur	n_s_Test	UDP	1194	V	Edit	Delete	
Teltonika	Status - Netw	ork - Services	s - Syst	tem -			Logout
OpenVPN IPsec GF	RE Tunnel PPT	P L2TP					
OpenVPN Instance	: Server_Tes	t					
Main Settings							
	Enable	Check this box if yo	ou want to sta	art OpenVPN			
	TUN/TAP	TUN (tunnel) 🔻					
	Protocol	UDP 💌					
	Port 1	1194					
	LZO 🛛	Check if you want	to compress	data			
	Encryption	BF-CBC 128 (default)) 🔻				
	Authentication	Static key 💌 Cł	hoose Static k	(ey			
Local	tunnel endpoint IP	172.16.0.1	Choo confi	se local and remote guration	IP as in Client		
Remote	tunnel endpoint IP	172.16.0.2					
Remote n	etwork IP address	192.168.50.0	Clie	ent IP address			
Remote	e network netmask	255.255.255.0	Cli	ent netmask			
Sta	tic pre-shared key U	ploaded File (636.00	B) 🗙 Up	oload generated key			
Back to Overview							Save

2.4.4 After that you will see a line with your tunnel. Press edit button to configure server.

2.5 Connect to server

2.5.2 After that open application "OpenVPN GUI". It should be already installed in your computer as bundle of "OpenVPN windows installer". Then you will see this "



2013.04.24 " two computers with red displays. Press on it with right mouse button and select "Connect".